

TS0183

How to refer TNA key of BioStar2 database

Created: 2016/12/30

Applies to: BioStar 2 2.3 versions or later

Abstract

BioStar2 devices support a function key to indicate the status of Time & Attendance such as CHECK-IN, CHECK-OUT, BREAK-IN, and etc.

To integrate 3rd party system, you need to distinguish an event type and a label for each log event.

This document describes how to refer a label of the T&A key.

Preparation

BioStar2 2.3 SW or higher


BioStar2 devices

Maria DB client

Reference document: TS0116 - BioStar 2 - Database Table Description V2.3.0.pdf


Procedure

- 1. Go to device menu.
- 2. Add a device.






3. Click on the device and click [Advanced].



- 4. Go T&A Event and set the T&A Event key
 - It can be up to 16.




- 5. Make a log with pressing T&A key on a device.
- 6. Run Maria DB Client such as Heidi SQL.
- 7. Connect "BioStar2_ac" DB.



8. Refer CAP column of t_takey table and t_lg_yyyymm table.

<t_takey>



<t_lgyyyymm>

